

Read this guide thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit and/or any devices it connects to:

1. Welcome

Congratulations on purchasing your ATAKE USB to parallel printer cable! Once again, ATAKE brings the cutting-edge technology of today and tomorrow to your Macintosh or PC. You will enjoy the convenience and high-speed that has made these technologies industry-standard.

Note:

Your order has been carefully packaged and inspected, and we hope you are pleased with the ATAKE product you purchased. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact your dealer immediately for assistance.

For general troubleshooting information, FAQ, and other related documents, we encourage you to check out our web site -- <http://www.ATAKE.com/html/support.html>

2. Features

- Convert any parallel (IEEE1284) printer to USB!
- Plug-n-Play installation -- Easy to install!
- Single cable design -- Great for notebook users!
- 100% Free Technical support -- No question too big or too small!

3. Requirements

- Windows 98SE or later
- 1 Available USB Port
- Parallel (IEEE 1284 compatible) printer

4. Installation Instruction (for Window® 98SE & ME)

NOTE: Ensure you have ALL Windows Critical Updates from the Microsoft Windows Update Site.

The Windows Update feature can be a convenient way to make sure you have all the latest patches and bug fixes that Microsoft didn't bother including in the boxed version of Windows.

However, if you have more than one computer, or you have a slow connection, it can be tedious and quite inconvenient to be forced to download all the files over and over again.

Please go to <http://windowsupdate.microsoft.com>, click on "Product Updates" to download the latest Critical Updates for your Windows OS.

Although there's no mention of it on the Windows Update site, Microsoft has made all of the updates available for separate download (for installing later) here:

<http://www.microsoft.com/windows98/downloads/corporate.asp>

Warning!

Carelessness in installing this device can result in permanent damage to your computer, and will void your warranty. Please use care any-time you open your Mac or PC and follow the manufacturer's guidelines for proper handling procedures.

Step. 1

With your computer booted up, plug the cable into the computer's USB port; its presence is automatically detected, and the New Hardware Wizard appears; click on Next to continue.

Step. 2

In the dialog box that comes up choose Search for the best drivers for your device; Click on **Next** to continue.

Step. 3

In the dialog box that comes up, choose the directory that has the current driver, as your source. Ex: C:\TEMP A:\ C:\Windows\Desktop

Step. 4

The dialog that comes up informs you that it has found the driver; Click on **Next** to continue. The driver file is now copied to your hard disk.

Step. 5

After the driver file has been copied to the hard disk, a dialog box appears to tell you that the installation has finished. Click on **Finish**. Windows now finishes up the installation.

Windows 2000/XP Users - Please Note

Windows 2000 and Windows XP have native driver support for the AUD-AM36PY120. After hooking up your printer, go into the Printer Properties, and select the printer port as "USB001". Your printer will now function as a native-USB printer.



ATake®

5. Radio & TV Interference Statement

WARNING!!! This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. This equipment has been tested and found to comply within the limits for a class B device, pursuant to Subpart J of Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial environment.

Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference. There is no guarantee that radio frequency interference will not be created in particular locations.

ATAKE® is not responsible for any radio or television interference caused by unauthorized modification of your mechanism or cables.

6. Limited Warranty

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK OR ITS DOCUMENTATION EXCEED THE PRICE PAID FOR THE PRODUCT.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose.

The direct vendor also reserves the right to, but not limited to, revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or updates. For further inquiries please contact your direct vendor.